


## To operate the Ignition switch;




1. Turn the handlebar fully to the left.


2. a. For parking push down the key in the ON position and turn it to P(Park).

**LOCK** b. For locking push down the key in the OFF position and turn it to LOCK

## Right Handlebar Switches

### Engine Stop Switch

In addition to the ignition switch, the engine stop switch must be in the  position for the motorcycle to operate.

The engine stop switch is for emergency use. If some emergency requires stopping the engine, move the engine stop switch to the  position.

### NOTE

- *Although the engine stop switch stops the engine, it does not turn off all the electrical circuits. Ordinarily, the ignition switch should be used to stop the engine.*