

## SAFE OPERATION

### Daily Safety Checks

Check the following items each day before you ride. The time required is minimal, and habitual performance of these checks will help ensure you a safe, reliable ride.

If any irregularities are found during these checks, refer to the Maintenance and Adjustment chapter or see your dealer for the action required to return the motorcycle to a safe operating condition.

#### WARNING

**Failure to perform these checks every day before you ride may result in serious damage or a severe accident.**

- Fuel..... Adequate supply in tank, no leaks.  
Engine oil..... Oil level between level lines.  
Tires..... Air pressure (when cold):

Front	Up to 181 kg (400 lb) Load	225 kPa (2.25 kg/cm <sup>2</sup> , 32 psi)
Rear	Up to 97.5 kg (215 lb) Load	250 kPa (2.50 kg/cm <sup>2</sup> , 36 psi)
	97.5 ~ 181 kg (215 ~ 400 lb) Load	280 kPa (2.80 kg/cm <sup>2</sup> , 41 psi)

Install the air valve cap.