

: The coolant temperature warning light goes on when the ignition key is turned to "ON" and goes off soon after the engine starts running to ensure that its circuit functions properly. The warning light also goes on whenever the coolant temperature rises to 120°C (248°F) or higher when the motorcycle is in operation. If it stays on, stop the engine and check the coolant level in the reserve tank after the engine cools down.

near the E(empty) position, refuel at the earliest opportunity.

CAUTION

Do not let the engine continue running when the warning light goes on. Prolonged engine operation will result in severe damage from overheating.

Fuel Gauge

The fuel gauge shows the amount of fuel in the fuel tank. When the needle comes