



A. Adjuster
B. Locknut

C. 2 ~ 3 mm
(0.08 ~ 0.12 in.)

If it does not, adjust the lever play as follows.

Adjustment

- Loosen the locknut at the clutch lever.
- Turn the adjuster so that the clutch lever will have 2 ~ 3 mm (0.08 ~ 0.12 in.) of play.

⚠ WARNING

Be sure the upper end of the clutch outer cable is fully seated in its fitting, or it could slip into place later, creating enough cable play to prevent clutch disengagement, resulting in a hazardous riding condition.

- Tighten the locknut.
- If it cannot be done, use the mounting nuts at the lower end of the cable.