

Operation	Frequency	*Odometer Reading km (mi)							
		Whichever comes first ↓	1,000 (600)	6,000 (4,000)	12,000 (7,500)	18,000 (12,000)	24,000 (15,000)	30,000 (20,000)	36,000 (24,000)
	Every								See Page
K Coolant-change	2 years					●			62
K Coolant filter-clean	years								62
Radiator hoses, connections-check †		●							59
K Steering stem bearing-lubricate	2 years					●			—
K Master cylinder cup and dust seal-replace	4 years								—
K Caliper piston seal and dust seal-replace	4 years								—
Drive chain-lubricate #		Every 600 km (400 mi)							83
Drive chain slack-check †#		Every 1,000 km (600 mi)							78

K : Should be serviced by an authorized Kawasaki dealer.

* : For higher odometer readings, repeat at the frequency interval established here.

† : Replace, add, adjust, or torque if necessary.

: Service more frequently when operating in severe conditions: dusty, wet, muddy, high speed, or frequent starting/stopping.