BMW Motorrad Maintenance schedule F 650 / F 650 ST



			n miles	nce miles	c >	
Customer	Licence No.	Mileage	BMW Inspection at 1000 km/600 miles	BMW Maintenance Service every 10000 km/6,000 miles	BMW Inspection every 20000 km/ 12,000 miles	Service
Job Order No.	Date	Mechanic's signature	BMW I	BMW N Service 10000 k	BMW In every 2 12,000	BMW Annual (
Change the engine oil while at regular operating temperature; renew the oil filter element If motorcycle is used only for short journeys or at outside temperatures below 0°C (32°F): every 3 months or at the latest after 3000 km (1800 miles)						
Clean the oil filter in the oil tank						
Change the oil in the telescopic fork						
Check the coolant and restore to correct level if necessary *						
Renew the coolant *) every two years						
Check valve clearances, adjust if necessary						
Renew the spark plug						
Clean or renew the intake air cleaner element If motorcycle is operated in very dirty or dusty conditions, clean or renew the intake air cleaner element every 10 000 km (6000 miles); check every 3000 km (1800 miles)						
Clean the fuel tap						
Check clutch play, adjust if necessary						
Grease the brake pedal						
Check wheel spoke tension and tighten if necessary more frequently if motorcycle is ridden in severe off-road conditions						
Check brake pads and discs for wear, renew if necessary *) more frequently if motorcycle is ridden in severe off-road conditions						
Check brake fluid level at front and rear; add fluid if necessary *)						
Check operation of brake system and freedom from leaks; repair/renew items if necessary *)						
Renew brake fluid at least once a year						
Check wheel bearings and renew if necessary *)						
Check chain, chainwheel, chain guide rollers and sprocket and renew if necessary *) more frequently if motorcycle is ridden in severe off-road conditions						
Check chain tension and adjust if necessary *)						
Check battery acid level, if necessary add distilled water more frequently if motorcycle is ridden in severe off-road conditions						
Clean/grease battery poles if necessary						
Check steering head bearings and adjust *) or renew *) if necessary						
Grease the side and centre stands						
Using a torque wrench, check that bolts and nuts on engine mountings, frame connections, exhaust system mountings, swinging fork pivot, suspension levers, brake pedal, centre and side stands and quick-release axles are tightened to specified torque						
Check CO value in exhaust and adjust if necessary on motorcycles with open-loop catalytic converter						
Check idle speed and adjust if necessary						
Final inspection with road safety and functional check: - clutch, gear shift - steering - handbrake, foot brake - condition of tyres and wheels, tyre pressures - lighting and signalling equipment, telltale lights, instruments - trial run if necessary						
*) Write up on separate invoi	ice: Not part of standard	service procedure				