

### *Fluid Change*

Have the brake fluid changed by an authorized Kawasaki dealer.

### **Front Brake:**

Disc and disc pad wear is automatically compensated for and has no effect on the brake lever action. So there are no parts that require adjustment on the front brake.

#### **WARNING**

**If the brake lever feels mushy when it is applied, there might be air in the brake lines or the brake may be defective. Since it is dangerous to operate the motorcycle under such conditions, have the brake checked immediately by an authorized Kawasaki dealer.**

### **Rear Brake:**

Brake pedal position can be adjusted to suit you. In accordance with the Periodic Maintenance Chart, inspect the brake pedal play.

#### *Pedal Position Inspection*

- When the brake pedal is in its rest position, it should be 0 ~ 20 mm (0 ~ 0.8 in.) lower than the top of the footpeg.