


A. Rear Brake Pedal

B. 0 ~ 20 mm (0 ~ 0.8 in.)

- If it is not, adjust the pedal position.

Pedal Position Adjustment

- Loosen the locknut, and turn the adjusting bolt to adjust the pedal position.
- Tighten the locknut.



A. Adjusting Bolt

B. Locknut

- Check the brake pedal play and operation of the rear break light switch.

Pedal Play Inspection

- The brake pedal should have 20 ~ 30 mm (0.8 ~ 1.2 in.) of play when the pedal is pushed down lightly by hand.