


**A. Rear Brake Pedal**

**B. 20 ~ 30 mm (0.8 ~ 1.2 in.)**

- Rotate the wheel to check for brake drag.
- Operate the pedal a few times to see that it returns to its rest position immediately upon release.
- Check braking effectiveness.
- If the pedal has improper play, adjust it.

### *Pedal Play Adjustment*

- Turn the adjusting nut at the brake cam lever so that the pedal has 20 ~ 30 mm (0.8 ~ 1.2 in.) of play.



**A. Adjusting Nut**