

OFF	Engine off. All electrical circuits off.
ON	Engine on. All electrical equipment can be used.
LOCK	Steering locked. Engine off. All electrical circuits off.
P(Park)	Steering locked. Engine off. Tail and city (except Australian model) lights on. All other electrical circuits cut off.

- *If you leave the P(Park) position on for a long time (one hour), the battery may become totally discharged.*

NOTE

- *The taillight is on whenever the ignition key is in the ON position. The headlight goes on when the starter button is released after starting the engine. To avoid battery discharge, always start the engine immediately after turning the ignition key to "ON."*