

## TABLE OF CONTENTS

<b>SPECIFICATIONS</b> .....	8	<b>Stands</b> .....	26
<b>LOCATION OF PARTS</b> .....	11	<b>Seat Lock</b> .....	28
<b>GENERAL INFORMATION</b> .....	14	<b>Tying Hooks</b> .....	28
Meter Instruments.....	14	<b>Helmet Hook</b> .....	29
Speedometer and Tachometer.....	15	<b>Tool Kit Compartment</b> .....	30
Indicator Lights.....	15	<b>Storage Compartment</b> .....	30
Key.....	17	<b>BREAK-IN</b> .....	32
Ignition Switch/Steering Lock.....	17	<b>HOW TO RIDE THE MOTORCYCLE</b> ....	34
Right Handlebar Switches.....	19	Starting the Engine.....	34
Engine Stop Switch.....	19	Jump Starting.....	37
Starter Button.....	20	Moving Off.....	39
Left Handlebar Switches.....	21	Shifting Gears.....	40
Dimmer Switch.....	21	Braking.....	41
Turn Signal Switch.....	21	Stopping the Engine.....	43
Horn Button.....	21	Stopping the Motorcycle in an	
Passing Button.....	21	Emergency.....	43
Fuel Tank Cap.....	22	Parking.....	44
Fuel Tank.....	23	Catalytic Converter.....	45
Fuel Tap.....	24	<b>SAFE OPERATION</b> .....	47
Brake/Clutch Lever Adjusters.....	26	Daily Safety Checks.....	47