

**ENGINE OIL AND OIL FILTER**

Engine Oil Change--when filter is not removed: 2.8 liters(3.0 US qt)  
when filter is removed: 3.0 liters(3.2 US qt)

Engine Oil Type: API SE, SF or SG  
: API SH or SJ with JASO MA  
SAE 10W-40

See Owner's Manual for engine oil / filter information and change intervals.

TE03273BN8 C