


## LOCATION OF PARTS



1. Clutch Lever
2. Meter Instruments
3. Indicator Lights
4. Brake Fluid Reservoir (Front)
5. Front Brake Lever

6. Left Handlebar Switches
7. Ignition Switch/Steering Lock
8. Right Handlebar Switches
9. Throttle Grip