


A. Fuel Tap
B. Screws

C. Fuel Hose
D. Vacuum Hose

- Pull the fuel hose and the vacuum hose off the fuel tap. Never pull off the fuel hoses from the fuel tank.
- Take off the fuel tank mounting bolt from the rear end of the tank and remove the tank.



A. Fuel Tank

B. Bolt

NOTE

- *For easier removal of the tank first twist the fuel tap so the fitting for the fuel hose to the carburetor faces upward and then push the tap up through the frame and carburetor.*
- Carefully pull the spark plug caps from the spark plugs.