

## Periodic Maintenance Chart

Operation	Frequency	Which ever comes first		*Odometer Reading							km (mi)
		Every	↓	1,000 (600)	6,000 (4,000)	12,000 (7,500)	18,000 (12,000)	24,000 (15,000)	30,000 (20,000)	36,000 (24,000)	
K Carburetor synchronization	-check †				●		●		●		75
					●		●		●		75
Idle speed-check †			●		●		●		●		75
Throttle grip play-check †			●		●		●		●		70
Spark plug-clean and gap †				●	●	●	●	●	●		63
K Valve clearance-check †					●		●		●		66
K Air suction valve-check †				●	●	●	●	●	●		67
Air cleaner element-clean † #					●		●		●		69
K Brake hose, connections	-check †			●	●	●	●	●	●		-
				●	●	●	●	●	●		-
Clutch-adjust			●	●	●	●	●	●	●		77
Brake play-check †			●	●	●	●	●	●	●		88
Brake light switch-check †			●	●	●	●	●	●	●		90
Brake lining or pad wear	-check † #			●	●	●	●	●	●		84
				●	●	●	●	●	●		84